

## SEZNAM PRODUKTŮ PRO DEAL 18V

| SKU        | NÁZEV                | Sloupec1   | Sloupec2             |
|------------|----------------------|------------|----------------------|
| 0611911120 | GBH 180-LI (solo)    | 06019K6106 | GSB 18V-90 C         |
| 0611911121 | GBH 180-LI           | 06019K6100 | GSB 18V-90 C (solo)  |
| 0611924020 | GBH 185-LI (solo)    | 06019J5101 | GSB 18V-150 C (solo) |
| 0611924021 | GBH 185-LI (solo)    | 06019J5102 | GSB 18V-150 C (solo) |
| 0611924022 | GBH 185-LI           | 06019J5105 | GSB 18V-150 C        |
| 0611924001 | GBH 185-LI           | 06019G030D | GSB 18V-110 C        |
| 0611923021 | GBH 187-LI           | 06019G030A | GSB 18V-110 C (solo) |
| 0611923022 | GBH 187-LI           | 06019K3000 | GSR 185-LI           |
| 0611923020 | GBH 187-LI (solo)    | 06019K3001 | GSR 185-LI           |
| 0611923120 | GBH 187-LI           | 06019K3003 | GSR 185-LI (solo)    |
| 0611923121 | GBH 187-LI           | 0615A5002N | GSR 18V-45           |
| 0611910003 | GBH 18V-26 F         | 06019H5001 | GSR 18V-50           |
| 0611910000 | GBH 18V-26 F (solo)  | 06019H5000 | GSR 18V-50           |
| 061191000E | GBH 18V-26 F         | 06019H5006 | GSR 18V-50 (solo)    |
| 061191000F | GBH 18V-26 F         | 06019G1102 | GSR 18V-60 C (solo)  |
| 061191000K | GBH 18V-26 F         | 06019N3200 | GSR 18V-65           |
| 0611909003 | GBH 18V-26           | 06019N3201 | GSR 18V-65           |
| 0611909000 | GBH 18V-26 (solo)    | 06019N3203 | GSR 18V-65           |
| 0611920000 | GBH 18V-28 C (solo)  | 06019N3206 | GSR 18V-65           |
| 0611921001 | GBH 18V-28 CF (solo) | 06019N3207 | GSR 18V-65           |
| 0611921002 | GBH 18V-28 CF        | 06019N3208 | GSR 18V-65           |
| 0611921003 | GBH 18V-28 CF        | 06019N3231 | GSR 18V-65           |
| 0611919001 | GBH 18V-28 DC (solo) | 06019N3232 | GSR 18V-65           |
| 0611919002 | GBH 18V-28 DC        | 06019K6003 | GSR 18V-90 C         |
| 0611914021 | GBH 18V-34 CF (solo) | 06019K6004 | GSR 18V-90 C         |
| 0611914002 | GBH 18V-34 CF        | 06019K6006 | GSR 18V-90 C         |
| 0611915021 | GBH 18V-36 C (solo)  | 06019K6000 | GSR 18V-90 C (solo)  |
| 0611915002 | GBH 18V-36 C         | 06019K6005 | GSR 18V-90 C         |
| 0611917120 | GBH 18V-40 (solo)    | 06019K6202 | GSR 18V-90 FC (solo) |
| 0611913120 | GBH 18V-45 C (solo)  | 06019K6203 | GSR 18V-90 FC (solo) |
| 0611913002 | GBH 18V-45 C         | 06019K6204 | GSR 18V-90 FC (solo) |
| 06019F8307 | GSB 180 LI           | 06019K6205 | GSR 18V-90 FC        |
| 06019K9100 | GSB 183-LI           | 06019K6200 | GSR 18V-90 FC        |
| 06019K9101 | GSB 183-LI           | 06019J5001 | GSR 18V-150 C (solo) |
| 06019K3100 | GSB 185-LI           | 06019J5002 | GSR 18V-150 C (solo) |
| 06019K3101 | GSB 185-LI           | 06019J5005 | GSR 18V-150 C        |
| 06019K3103 | GSB 185-LI (solo)    | 06019G0109 | GSR 18V-110 C (solo) |
| 06019H5106 | GSB 18V-50 (solo)    | 06019G010C | GSR 18V-110 C        |
| 06019H5100 | GSB 18V-50           | 06019M7020 | ISR 18V-30 P         |
| 06019H5101 | GSB 18V-50           | 06019M7021 | ISR 18V-30 P         |
| 06019N3300 | GSB 18V-65           | 06019M7120 | ISR 18V-30 PHX       |
| 06019N3301 | GSB 18V-65           | 06019M7121 | ISR 18V-30 PHX       |
| 06019N3303 | GSB 18V-65           | 06019G7101 | GSR 18V-60 FC Flex   |
| 06019N3306 | GSB 18V-65           | 06019G6121 | GDS 250-LI (solo)    |
| 06019N3307 | GSB 18V-65           | 06019G6120 | GDS 250-LI           |
| 06019N3308 | GSB 18V-65           | 06019G5123 | GDR 180-Li           |
| 06019N3332 | GSB 18V-65           | 06019G5124 | GDR 180-LI           |
| 06019N3100 | GSB 18V-65           | 06019G5106 | GDR 18V-160          |
| 06019K6103 | GSB 18V-90 C         | 06019J2105 | GDR 18V-200 (solo)   |
| 06019K6104 | GSB 18V-90 C         | 06019J2106 | GDR 18V-200          |

|            |                             |            |                        |
|------------|-----------------------------|------------|------------------------|
| 06019J2107 | GDR 18V-200                 | 06019M3120 | GKS 18V-51             |
| 06019G4104 | GDR 18V-200 C (solo)        | 06019M3122 | GKS 18V-51             |
| 06019G4101 | GDR 18V-200 C               | 06016C9001 | GKS 18V-68             |
| 06019N2000 | GDR 18V-215                 | 06016C9000 | GKS 18V-68             |
| 06019N2002 | GDR 18V-215                 | 06016B5100 | GKS 18V-68 GC (solo)   |
| 06019N2020 | GDR 18V-215                 | 06016B5101 | GKS 18V-68 GC          |
| 06019N2022 | GDR 18V-215                 | 06016B5000 | GKS 18V-68 C (solo)    |
| 06019L6000 | GDR 18V-220 C (solo)        | 06016A2101 | GKS 18 V-57 G (solo)   |
| 06019L6003 | GDR 18V-220 C               | 06016A2200 | GKS 18 V-57 (solo)     |
| 06019G5222 | GDX 180-LI + GSR 180        | 06016C1000 | GKS 18V-57-2 GX        |
| 06019G5223 | GDX 180-Li                  | 06016C1001 | GKS 18V-57-2 GX        |
| 06019G5226 | GDX 180-Li (solo)           | 06016C1003 | GKS 18V-57-2 GX        |
| 06019J2204 | GDX 18V-200 (solo)          | 06016C1221 | GKS 185-LI (solo)      |
| 06019J2205 | GDX 18V-200                 | 06016C1224 | GKS 185-Li (sólo)      |
| 06019J2206 | GDX 18V-200                 | 06016C1223 | GKS 185-Li             |
| 06019G4204 | GDX 18V-200 C (solo)        | 06016B8000 | GKM 18V-50 (sólo)      |
| 06019G4201 | GDX 18V-200 C               | 06016B8002 | GKM 18V-50             |
| 06019J0200 | GDX 18V-210 C               | 06016B4000 | GKT 18V-52 GC (solo)   |
| 06019J0201 | GDX 18V-210 C               | 06013B0000 | GCS 18V-230            |
| 06019N2100 | GDX 18V-285                 | 06015A6100 | GST 18 V-LI B (solo)   |
| 06019N2102 | GDX 18V-285                 | 06015A5100 | GST 18 V-LI S (solo)   |
| 06019N2120 | GDX 18V-285                 | 06015B0002 | GST 18V-155 SC         |
| 06019N2122 | GDX 18V-285                 | 06015B0000 | GST 18V-155 SC (solo)  |
| 06019D8200 | GDS 18V-300 (solo)          | 06015B0001 | GST 18V-155 SC (solo)  |
| 06019D8201 | GDS 18V-300 (solo)          | 06015B7020 | GST 183-LI (solo)      |
| 06019M5020 | GDS 18V-350                 | 06015B7022 | GST 183-LI             |
| 06019M5021 | GDS 18V-350                 | 06015B3021 | GST 185-LI (solo)      |
| 06019K0021 | GDS 18V-400                 | 06015B3023 | GST 185-LI             |
| 06019K0020 | GDS 18V-400                 | 06015B3024 | GST 185-LI             |
| 06019K4101 | GDS 18V-450 PC (solo)       | 06015B2021 | GST 185-LI (solo)      |
| 06019K4102 | GDS 18V-450 PC              | 06015B2022 | GST 185-LI             |
| 06019K4103 | GDS 18V-450 PC              | 06015B1002 | GST 18V-155 BC         |
| 06019L9000 | GDS 18V-750 C               | 06015B1000 | GST 18V-155 BC (solo)  |
| 06019L9001 | GDS 18V-750 C               | 06015B1001 | GST 18V-155 BC (solo)  |
| 06019L9002 | GDS 18V-750 C               | 0601B43000 | GCM 18V-305 GDC (solo) |
| 06019L9003 | GDS 18V-750 C               | 0601B43001 | GCM 18V-305 GDC        |
| 06019J8300 | GDS 18V-1000                | 0601B43002 | GCM 18V-305 GDC        |
| 06019J8304 | GDS 18V-1000                | 0601B41000 | GCM 18V-216 (solo)     |
| 06019J8001 | GDS 18V-1000 C (solo)       | 0601B51000 | GCM 18V-216 D (solo)   |
| 06019J8500 | GDS 18V-1050 H (solo)       | 0601B47000 | GCM 18V-216 DC (solo)  |
| 06019J8522 | GDS 18V-1050 H              | 0601B51100 | GCM 18V-254 D (solo)   |
| 06019J8502 | GDS 18V-1050 H              | 06016A8108 | GSA 18V-32             |
| 06019M1000 | GDS 18V-1600 HC             | 060164J000 | GSA 18 V-LI (solo)     |
| 06019M1002 | GDS 18V-1600 HC             | 060164J007 | GSA 18V-LI (solo)      |
| 06019N0020 | IDS 18V-200T                | 06016A5002 | GSA 18 V-LI C          |
| 06019N0021 | IDS 18V-200T                | 06016A5001 | GSA 18 V-LI C (solo)   |
| 06019C6200 | GAS 18V-1 (solo)            | 06016A5004 | GSA 18 V-LI C (solo)   |
| 06019c6302 | GAS 18V-10 L Premium (solo) | 06016C0020 | GSA 185-Li (solo)      |
| 06019K2000 | GAS 18V-12 MC (solo)        | 06016C0021 | GSA 185-LI             |
| 06019F5100 | GBL 18V-120 (solo)          | 06018G2020 | GOP 185-LI (solo)      |
| 06012A0400 | GCB 18V-63 (solo)           | 06018G2021 | GOP 185-LI             |
| 06012B7000 | GCB 18V-127 (solo)          | 06019D0200 | GSS 18V-10 (solo)      |
| 06015A0307 | GHO 18V-Li (solo)           | 06019D0202 | GSS 18 V-10 (solo)     |
| 06015B5021 | GHO 185-LI (solo)           | 06019D0201 | GSS 18V-10             |

|            |                                |            |                       |
|------------|--------------------------------|------------|-----------------------|
| 06019L0100 | GSS 18V-13 (solo)              | 06019M2000 | GPT 18V-19            |
| 06019L0101 | GSS 18V-13 (solo)              | 06019M2001 | GPT 18V-19            |
| 0601372201 | GEX 18V-125                    | 06019M2002 | GPT 18V-19            |
| 0601372904 | GEX 18V-150-3                  | 06019M2003 | GPT 18V-19            |
| 0601372903 | GEX 18V-150-3                  | 06019M2004 | GPT 18V-19            |
| 0601529601 | GNA 18V-16 E                   | 06019M2100 | GPT 18V-32            |
| 0601529600 | GNA 18V-16 E (solo)            | 06019M2101 | GPT 18V-32            |
| 0601926301 | GSC 18V-16 E                   | 06019M2102 | GPT 18V-32            |
| 0601926300 | GSC 18V-16 E (solo)            | 06019M2103 | GPT 18V-32            |
| 06012B4000 | GGs 18V-10 SLC                 | 06019M2104 | GPT 18V-32            |
| 06012B4001 | GGs 18V-10 SLC                 | 06019K8000 | GCU 18V-30            |
| 06019B5401 | GGs 18V-20 (solo)              | 06016C2000 | GKF 18V-8             |
| 0601229100 | GGs 18V-23 LC (solo)           | 06016C2001 | GKF 18V-8             |
| 0601229200 | GGs 18V-23 PLC (solo)          | 06016C2003 | GKF 18V-8             |
| 06019H9022 | GWS 180-LI (solo)              | 06016C6000 | GLF 18V-8 (solo)      |
| 06019H9020 | GWS 180-LI (solo)              | 06016C6001 | GLF 18V-8 (solo)      |
| 06019H9021 | GWS 180-LI                     | 06016C6020 | GLF 18V-8 (solo)      |
| 06019N9000 | GWS 18V-8                      | 0601620100 | GFF 18V-22            |
| 06019N9001 | GWS 18V-8                      | 0601620101 | GFF 18V-22            |
| 06019N9002 | GWS 18V-8                      | 060160A800 | TE 600                |
| 06019N9003 | GWS 18V-8                      | 06019C4001 | GCG 18V-600 (solo)    |
| 06019N9004 | GWS 18V-8                      | 06019C4100 | GCG 18V-310 (solo)    |
| 06019N9020 | GWS 18V-8                      | 0601443400 | GLI VariLED           |
| 06019N9021 | GWS 18V-8                      | 06014A1100 | GLI 18V-300           |
| 06019J4000 | GWS 18V-10 (solo)              | 0601443600 | GLI 18V-800           |
| 06019J4002 | GWS 18V-10 (solo)              | 0601446400 | GLI 18 V-1900         |
| 06019J4004 | GWS 18V-10                     | 0601446700 | GLI 18V-1200 C (solo) |
| 06019J4100 | GWS 18V-10 P                   | 0601446501 | GLI 18V-2200 C (solo) |
| 06019J4101 | GWS 18V-10 P                   | 0601446800 | GLI 18V-4000 C        |
| 06019J4200 | GWX 18V-10 P                   | 06019P0200 | GLH 18V-60            |
| 06019G340B | GWS 18V-10 SC                  | 06019P0100 | GPH 18V-60            |
| 06019G350B | GWS 18V-10 SC (solo)           | 06019P0000 | GKH 18V-50            |
| 06019G3F0D | GWS 18V-10 PSC                 | 06011C2000 | GRW 18V-120           |
| 06019N4100 | GWS 18V-11                     | 06011C3000 | GRW 18V-160           |
| 06019N4101 | GWS 18V-11                     | 06014A4000 | GPB 18V-5 C (solo)    |
| 06019N4102 | GWS 18V-11                     | 06014A3000 | GPB 18V-2 C (solo)    |
| 06019N4103 | GWS 18V-11                     | 06014A4100 | GPB 18V-5 SC (solo)   |
| 06019N4000 | GWS 18V-11 S                   | 06014A3100 | GPB 18V-2 SC (solo)   |
| 06019N4001 | GWS 18V-11 S                   | 06014A6000 | GPB 18V-6 C           |
| 06019N4002 | GWS 18V-11 S                   | 06014A6200 | GPB 18VH-6 SRC        |
| 06019N4003 | GWS 18V-11 S                   | 06019L7000 | GNB 18V-38 (solo)     |
| 06019H6000 | GWS 18V-15 C (solo)            | 06019L7001 | GNB 18V-38 (solo)     |
| 06019H6A00 | GWS 18V-15 P (solo)            | 06019L7002 | GNB 18V-38            |
| 06019H6100 | GWS 18V-15 SC (solo)           | 06019L7004 | GNB 18V-40            |
| 06019H6101 | GWS 18V-15 SC                  | 06019L7005 | GNB 18V-40            |
| 06019H6B00 | GWS 18V-15 PSC (solo)          | 0601481000 | GNH 18V-64 M (solo)   |
| 06019H6L01 | GWS 18V-180 P (solo)           | 0601481001 | GNH 18V-64 M (solo)   |
| 06019H6E01 | GWS 18V-180 PC (solo)          | 0601481003 | GNH 18V-64 M          |
| 06017B0100 | GWX 18V-10 (X-LOCK) (solo)     | 0601481100 | GNH 18V-64 (solo)     |
| 06017B0700 | GWX 18V-10 PC (X-LOCK) (solo)  | 0601481101 | GNH 18V-64 M (solo)   |
| 06017B0800 | GWX 18V-10 PSC (X-LOCK) (solo) | 0601482100 | GNH 18V-64-2          |
| 06017B0400 | GWX 18V-10 SC (X-LOCK) (solo)  | 0601482001 | GNH 18V-64-2 M        |
| 06019H6500 | GWX 18V-15 SC (X-LOCK) (solo)  | 0601482500 | GTH 18V-38 M (solo)   |
| 06019H6501 | GWX 18V-15 SC (X-LOCK)         | 0601482501 | GTH 18V-38 M (solo)   |

|            |                                         |            |                                   |
|------------|-----------------------------------------|------------|-----------------------------------|
| 06012A6501 | GHG 18V-50 (solo)                       | 06188000DY | GHJ 12+18V XA M (solo)            |
| 06012A6500 | GHG 18V-50 (solo)                       | 06188000E0 | GHJ 12+18V XA XL (solo)           |
| 06019K5000 | GRG 18V-16 C                            | 06188000EE | GHV 12+18V XA                     |
| 06019K5001 | GRG 18V-16 C                            | 06188000DX | GHJ 12+18V XA                     |
| 06019K7022 | GTB 185-LI                              | 06188000EC | GHV 12+18V XA                     |
| 06019K7020 | GTB 185-LI                              | 06188000EB | GHV 12+18V XA                     |
| 06019K7021 | GTB 185-LI (solo)                       | 06188000ED | GHV 12+18V XA                     |
| 06188000E1 | GHJ 12+18V XA 2XL (solo)                | 06019G5227 | GSR 18V-50 + GDX 180-LI           |
| 06188000DZ | GHJ 12+18V XA L (solo)                  | 06019H5004 | GSR 18V-50                        |
| 06188000DY | GHJ 12+18V XA M (solo)                  | 06019H5005 | GSR 18V-50                        |
| 06188000E0 | GHJ 12+18V XA XL (solo)                 | 06019H5121 | GSB 18V-50                        |
| 06188000EE | GHV 12+18V XA                           | 06019J2220 | GSR 18V-50 + GDX 18V-200          |
| 06188000DX | GHJ 12+18V XA                           | 0615990M30 | GBH 180 LI + GDX 180 LI           |
| 06188000EC | GHV 12+18V XA                           | 0615990M31 | GBH 180-LI + GSR 180-LI           |
| 06188000EB | GHV 12+18V XA                           | 0615990M33 | GBH 180-LI                        |
| 06188000ED | GHV 12+18V XA                           | 0615990N05 | GBH 180-LI+ GWS 180-LI            |
| 06019G5227 | GSR 18V-50 + GDX 180-LI                 | 0615990M3N | GBH 18V-26                        |
| 06019H5004 | GSR 18V-50 + 43 ks ACC                  | 0615990M3Y | GSA 18 V-LI C                     |
| 06019H5005 | GSR 18V-50                              | 0615990M47 | GWS 180-LI + GSR 18V-50           |
| 06019H5121 | GSB 18V-50                              | 06019F8308 | GBH 180-LI                        |
| 06019J2220 | GSR 18V-50 + GDX 18V-200                | 0615990M9C | GBH 180-LI                        |
| 0615990M30 | GBH 180 LI + GDX 180 LI                 | 0615990M9K | GWS 18V-10 + GSB 18V-50           |
| 0615990M31 | GBH 180-LI + GSR 180-LI                 | 061191000G | GBH 18V-26 F + GDE 18V-16         |
| 0615990M33 | GBH 180-LI                              | 0615990M9F | GBH18V-26+GDX18V-200C+GWS18V      |
| 0615990N05 | GBH 180-LI + GWS 180-LI                 | 06019K0003 | GDS 18V-400 + GSB 18V-50          |
| 0615990M3N | GBH 18V-26                              | 06019F810A | GSR 180-LI                        |
| 0615990M3Y | GSA 18 V-LI C                           | 0615990M5G | GBH 180-LI + GWS 180-LI + GDX 18V |
| 0615990M47 | GWS 180-LI + GSR 18V-50                 | 0615990M32 | GBH 180-LI + GSR 18V-50 + GWS 18V |
| 06019F8308 | GSB 180-LI                              | 0615990N21 | GBH 18V-26 + GDX 18V-200 + GWS    |
| 0615990M9C | GBH 180-LI                              | 0615990N3F | GDX 180-LI + GSR 18V-50           |
| 0615990M9K | GWS 18V-10 + GSB 18V-50                 | 0615990N42 | GBH 187-LI + GWS 18V-10 + GSR 18V |
| 061191000G | GBH 18V-26 F + GDE 18V-16               | 0615990M8K | GSB 18V-50                        |
| 0615990M9F | GBH 18V-26 + GDX 18V-200 C + GWS 18V-10 | 0615990N1U | GDX 180-LI + GWS 180-LI           |
| 06019K0003 | GDS 18V-400 + GSB 18V-50                | 0615990N25 | GSR 185-LI                        |
| 06019F810A | GSR 180-LI                              | 0615990N1Z | GSB 185-LI                        |
| 0615990M5G | GBH 180-LI + GWS 180-LI + GDX 180-LI    | 0615990N20 | GBH 180-LI + GSR 185-LI           |
| 0615990M32 | GBH 180-LI + GSR 18V-50 + GWS 180-LI    | 0615990N3P | GSR 185-LI + GDX 180-LI + GWS 18V |
| 0615990N21 | GBH 18V-26 + GDX 18V-200 + GWS 18V-10   | 0615A5002S | GSR 18V-110 C                     |
| 0615990N3F | GDX 180-LI + GSR 18V-50                 | 0615A5002X | GSB 18V-110 C                     |
| 0615990N42 | GBH 187-LI + GWS 18V-10 + GSR 18V-50    | 0615A5002T | GSR 18V-150 C                     |
| 0615990M8K | GSB 18V-50                              | 0615A5002Y | GSB 18V-150 C                     |
| 0615990N1U | GDX 180-LI + GWS 180-LI                 | 0615A5002R | GSR 18V-90 C                      |
| 0615990N25 | GSR 185-LI                              | 0615A5002W | GSB 18V-90 C                      |
| 0615990N1Z | GSB 185-LI                              | 06019L6023 | GSR 18V-90 C + GDR 18V-220 C      |
| 0615990N20 | GBH 180-LI                              | 0615A5004H | GEX 18V-125 + M480                |
| 0615990N3P | GSR 185-LI + GDX 180-LI + GWS 180-LI    | 0615990M94 | GKS 18V-68GC+FSN1400              |
| 0615A5002S | GSR 18V-110 C                           | 0615A5002D | GWS 18V-180 P                     |
| 0615A5002X | GSB 18V-110 C                           | 0615990N32 | GSR18V-110C+GDX 18V-210C+GWS      |
| 0615A5002T | GSR 18V-150 C                           | 0615990N34 | GSR18V-90C+GDR18V-210+GBH18V      |
| 06019K7022 | GTB 185-LI                              | 06188000DY | GHJ 12+18V XA M (solo)            |
| 06019K7020 | GTB 185-LI                              | 06188000E0 | GHJ 12+18V XA XL (solo)           |
| 06019K7021 | GTB 185-LI (solo)                       | 06188000EE | GHV 12+18V XA                     |
| 06188000E1 | GHJ 12+18V XA 2XL (solo)                | 06188000DX | GHJ 12+18V XA                     |
| 06188000DZ | GHJ 12+18V XA L (solo)                  | 06188000EC | GHV 12+18V XA                     |

|            |                                                |            |                        |
|------------|------------------------------------------------|------------|------------------------|
| 06188000EB | GHV 12+18V XA                                  |            |                        |
| 06188000ED | GHV 12+18V XA                                  | 06008D2000 | GBL 18V-750 (solo)     |
| 06019G5227 | GSR 18V-50 + GDX 180-LI                        | 06008C9500 | GHE 18V-50 (solo)      |
| 06019H5004 | GSR 18V-50                                     | 06008C9000 | GHE 18V-60 (solo)      |
| 06019H5005 | GSR 18V-50                                     | 06008D5000 | GHE 18V-50 TP          |
| 06019H5121 | GSB 18V-50                                     | 06008D0000 | GRT 18V-33 (solo)      |
| 06019J2220 | GSR 18V-50 + GDX 18V-200                       | 06008D1000 | GFR 18V-23 (solo)      |
| 0615990M30 | GBH 180 LI + GDX 180 LI                        | 06008C8000 | GRA 18V2-46 (solo)     |
| 0615990M31 | GBH 180-LI + GSR 180-LI                        | 06008D3000 | GKE 18V-40 (solo)      |
| 0615990M33 | GBH 180-LI                                     | 06008D6000 | GKE 18V-25 TP          |
| 0615990N05 | GBH 180-LI+ GWS 180-LI                         | 0601065100 | GLL 18V-120-33 CG+DK20 |
| 0615990M3N | GBH 18V-26                                     | 0601065101 | GLL 18V-120-33 CG+DK20 |
| 0615990M3Y | GSA 18 V-LI C                                  |            |                        |
| 0615990M47 | GWS 180-LI + GSR 18V-50                        |            |                        |
| 06019F8308 | GBH 180-LI                                     |            |                        |
| 0615990M9C | GBH 180-LI                                     |            |                        |
| 0615990M9K | GWS 18V-10 + GSB 18V-50                        |            |                        |
| 061191000G | GBH 18V-26 F + GDE 18V-16                      |            |                        |
| 0615990M9F | GBH 18V-26+ GDX 18V-200 C + GWS 18V-10         |            |                        |
| 06019K0003 | GDS 18V-400 + GSB 18V-50                       |            |                        |
| 06019F810A | GSR 180-LI                                     |            |                        |
| 0615990M5G | GBH 180-LI + GWS 180-LI + GDX 180-LI           |            |                        |
| 0615990M32 | GBH 180-LI + GSR 18V-50 + GWS 180-LI           |            |                        |
| 0615990N21 | GBH 18V-26 + GDX 18V-200 + GWS 18V-10          |            |                        |
| 0615990N3F | GDX 180-LI + GSR 18V-50                        |            |                        |
| 0615990N42 | GBH 187-LI + GWS 18V-10 + GSR 18V-50           |            |                        |
| 0615990M8K | GSB 18V-50                                     |            |                        |
| 0615990N1U | GDX 180-LI + GWS 180-LI                        |            |                        |
| 0615990N25 | GSR 185-LI                                     |            |                        |
| 0615990N1Z | GSB 185-LI                                     |            |                        |
| 0615990N20 | GBH 180-LI + GSR 185-LI                        |            |                        |
| 0615990N3P | GSR 185-LI + GDX 180-LI + GWS 180-LI           |            |                        |
| 0615A5002S | GSR 18V-110 C                                  |            |                        |
| 0615A5002X | GSB 18V-110 C                                  |            |                        |
| 0615A5002T | GSR 18V-150 C                                  |            |                        |
| 0615A5002Y | GSB 18V-150 C                                  |            |                        |
| 0615A5002R | GSR 18V-90 C                                   |            |                        |
| 0615A5002W | GSB 18V-90 C                                   |            |                        |
| 06019L6023 | GSR 18V-90 C + GDR 18V-220 C                   |            |                        |
| 0615A5004H | GEX 18V-125 + M480                             |            |                        |
| 0615990M94 | GKS 18V-68GC+FSN1400                           |            |                        |
| 0615A5002D | GWS 18V-180 P                                  |            |                        |
| 0615990N32 | GSR18V-110C+GDX18V-210C+GWS18V-10+GBH18V-24C   |            |                        |
| 0615990N34 | GSR18V-90C+GDR18V-210C+GBH18V-24C+GOP18V-28    |            |                        |
| 0615990N38 | GSB18V-110C+GKS18V-68GC+GSA18V-28              |            |                        |
| 0615990N3A | GSR18V-90C+GWS18V-15PSC+GKM18V-50+GGS18V-23PLC |            |                        |
| 0615990N36 | GSR18V-90C+GKT18V-52GC+GST18V-155SC+GEX18V-125 |            |                        |
| 0615990N37 | GS 18V-90C+GDX18V-210C+GBH18V-24+GSA18V-28     |            |                        |
| 06019N2123 | GDX 18V-285 + GSR 185-LI                       |            |                        |
| 06019N2124 | GDX 18V-285 + GSB 185-LI                       |            |                        |
| 06019N2023 | GDR 18V-215 + GSR 185-LI                       |            |                        |
| 06019N2024 | GDR 18V-215 + GSB 185-LI                       |            |                        |
| 0615A50061 | GSR 18V-45 + GBH 18V-22 + GWS 18V-8            |            |                        |
| 0615V0001Y | GSB 18V-45 + GWS 18V-8                         |            |                        |